


UPDATE THIS  
Do not connect ext 5V power and USB at the same time.



Notes:

JP\_Ix- jumpers bridged for single-ended (normal) operation.

J9 bridged if AUX input (additional ADC) unused.

For AC coupled, single-ended ...

For DC coupled, differential ... link 1&2

